

Keys-To-Go


Ultra-portable keyboard for Android™ and Windows® **aK1041** 超便携键盘 适用于 Android™ 和 Windows®



Contents / 目录

English	简体中文
---------	------

Know your product



- 1. Hot keys
- 2. Keyboard
- 3. Bluetooth® connect key
- 4. Battery check key
- 5. Bluetooth and battery status light

- 6. On/off switch
- 7. Micro-USB charging port
- 8. Micro-USB charging cable
- 9. Documentation

Set up your product

1. Turn on the keyboard:



Bluetooth discovery starts automatically and continues for 15 minutes. The status light blinks blue.

If the status light briefly turns red, charge the battery. For more information, see "Charge the battery."

2. Establish Bluetooth connection:



Make sure your tablet's *Bluetooth* feature is on. Go to Settings > Network connections section, and turn on the *Bluetooth* function.

- 3. Pair the keyboard with your tablet:
 - (i) In your tablet's *Bluetooth* settings page, select "Keys-To-Go AW" in the list of Available devices.
 - (ii) When prompted, enter the PIN displayed using the keyboard.

When successful connection is made, the status light turns solid blue for a short time, and then turns off.


(iii) Press enter to confirm the PIN code.

Tip: If "Keys-To-Go AW" isn't in the list, you can try pressing and holding the *Bluetooth* connect key on your keyboard for 2 seconds or press scan (or equivalent) on your tablet to search for *Bluetooth* devices.

Charge the battery

You should charge the battery when:


- the status light turns red briefly when you turn on the keyboard, or
- the status light blinks red when you press the battery check key:



A fully charged battery provides about 3 months of power when the keyboard is used about two hours a day.

Charging your battery

 Use the micro-USB charging cable provided to connect the keyboard to your computer or a USB power adaptor. The status light blinks green while the keyboard is charging.



2. Charge your keyboard until the status light turns solid green.

Each minute of charging gives you about two hours' use.

Note: This ratio is approximate and is based on the standard user experience. Your result may vary. It takes 2.5 hours to fully charge the battery.

Hot keys

← fn + Back: Esc

Android home/
Windows browser home

Switch applications

Android menu/
Windows contextual menu

✓ Mail

☐ Music

♣ Previous track

Play/Pause

» Next track

Volume down

▼ Volume up

Print screen

→ Bluetooth connect

fn + battery check:
Android lock screen/
Windows 8 lock screen/
Windows 7 sleep

Function keys



fn +Up arrow = Page up

fn + C = Copy

fn + Down arrow = Page down

v fn + V = Paste

fn + Right arrow = end

₩ Windows Start key

fn + Back = Forward delete

Q Android search/Windows search

For Android:
ctrl + space =
Language layout switch*

fn + Left arrow = Home

For Windows:
alt + shift =
Language layout switch*


Note: To select a function key, press and hold the fn key, and then press the key indicated above.

*Language layout switch:

- 1. Choose the key combination which is applicable to your specific operating system.
- 2. Please ensure you have more than one language layout selected in order to switch between them.

Use your product

Status light indications



Light	Description
Blinking green	The battery is charging.
Solid green	When charging, indicates that the battery is fully charged (100%).
	When you press the battery check key, solid green for 2 seconds indicates that the battery power is good (above 20%).
Blinking red	Battery power is low (less than 20%). Recharge the battery.
Solid red	When you first turn on your keyboard, the status light shows solid red briefly if battery power is low.
Blinking blue	Fast: The keyboard is in discovery mode, ready for pairing.
	Slow: The keyboard is trying to reconnect to your tablet.
Solid blue	Bluetooth pairing or reconnection is successful.

Connecting to a different device

- 1. Make sure the keyboard is turned on.
- 2. On your device, check that Bluetooth is turned on. Select Settings > Bluetooth > On.
- 3. Press and hold the Bluetooth connect key on the keyboard for 2 seconds. The keyboard turns discoverable for 3 minutes.
- 4. Select "Keys-To-Go AW" from the Devices menu.



Use with optional Smartphone Stand

- 1. Attach the stand to the keyboard.
- 2. Set your smartphone in stand.
- 3. You are ready to type.







When you've finished using your product When not in use, turn off the keyboard to conserve battery power.





Note:

· The keyboard enters sleep mode if powered on and not used for 2 hours. To exit sleep mode, press any key.

Battery disposal at product end of life

1. Cut along the fabric at the top edge of the keyboard:



2. Use a screwdriver to pry the fabric away from the area around the on/off switch:



3. Separate the inner and outer fabric layers, and pull them away from the corner:



4. Pull back the yellow plate to reveal the battery and remove it:



5. Dispose of the battery according to local laws.



Visit Product Support

There's more information and support online for your product. Take a moment to visit Product Support to learn more about your new Bluetooth keyboard.

Browse online articles for setup help, usage tips, and information about additional features. If your Bluetooth keyboard has optional software, learn about its benefits and how it can help you customize your product.

Connect with other users in our Community Forums to get advice, ask questions, and share solutions.

At Product Support, you'll find a wide selection of content including:

- Tutorials
- Troubleshooting
- · Support community
- · Online documentation
- · Warranty information
- Spare parts (when available)

Go to:

www.logitech.com/support/keystogo-tablet

Troubleshooting

The keyboard does not work

- Press any key to wake the keyboard from sleep mode.
- · Turn the keyboard Off and then back On.
- Recharge the internal battery. For more information, see "Charge the battery."
- Re-establish the Bluetooth connection between the keyboard and your tablet:
 - On your tablet, check that Bluetooth is turned on.
 - Press and hold the Bluetooth connect key on your keyboard for 2 seconds.
 - Choose "Keys-To-Go AW" from the Devices menu on your tablet. The status light briefly turns blue after the Bluetooth connection is made.


Note: If you have any language compatibility issue, please install the "Logitech Keyboard plus" application on your tablet or contact Logitech Customer Care to get further information: www.logitech.com/support/keystogo-tablet

What do you think?

Thank you for purchasing our product. Please take a minute to tell us what you think of it.

www.logitech.com/ithink

了解您的产品



- 1. 热键
- 2. 键盘
- 3. 蓝牙‴连接按键
- 4. 电池电量检查按键
- 5. 蓝牙和电池状态指示灯

- 6. 开启/关闭开关
- 7. 微型 USB 充电端口
- 8. 微型 USB 充电连接线
- 9. 文档

设置您的产品

1. 开启键盘:



- 2. 蓝牙搜索功能自动开启,将持续 15 分钟。状态指示灯将闪烁蓝灯。 如果状态指示灯短暂变为红灯,请为电 池充电。有关详细信息,请参见"为电 池充电"。
- **3.** 建立*蓝牙*连接:



4. 确保平板电脑的*蓝牙*功能已开启。进入设置 > 网络连接,开启*蓝牙*功能。


- 5. 将键盘与平板电脑配对:
- 6. (i) 在平板电脑的蓝牙设置页面,从可用设备列表中选择"Keys-To-Go AW"。
 - (ii) 根据提示,通过键盘输入显示的 PIN。 成功连接后,状态指示灯将在短时间内变 为稳定蓝灯,然后熄灭。
 - (iii) 按回车键确认 PIN 码。

提示: 如果 "Keys-To-Go AW" 未出现在列表中, 可尝试按住键盘上的蓝牙连接按键并持续 2 秒钟, 或者按下平板电脑上的扫描(或类似功能)按键来搜 索蓝牙设备。

为电池充电

出现以下情况时, 应对电池进行充电:


- ・ 开启键盘后, 状态指示灯短暂亮起红灯, 或
- ·按电池电量检查键时,状态指示灯闪烁 红灯:



电池充满电之后,如果键盘每天使用约两个小时,则电量可以维持三个月。

为电池充电

1. 使用随附的微型 USB 充电连接线将键盘 连接至电脑或 USB 电源适配器。键盘充 电过程中、状态指示灯将闪烁绿灯。



2. 为键盘充电,直到状态指示灯变为稳定的绿灯为止。

每充电一分钟可使用大约两小时。

请注意:该使用时间基于标准用户操作,为大概值。 具体使用时间因人而异。

电池完全充满电需要 2.5 个小时。

热键

- →[∞] fn + 后退: Esc
- Android 主界面/Windows 浏览器主页
- □ 切换应用程序
- Android 菜单/Windows 上下文菜单
- 邮件
- → 音乐
- ₩ 上一曲目

- ▶□ 播放/暂停
- 下一曲目
- 调低音量
- → 调高音量
- 全屏截图
- → 蓝牙连接
- fn + 电池电量检查: Android 锁屏/ Windows 8 锁屏/ Windows 7 休眠

功能键

fn + 向上箭头 = 上页



『 fn + 向下箭头 = 下页



▶ fn + 向右箭头 = 结束

■ Windows 开始键

fn + 后退 = 向前删除

- Q Android 搜索/Windows 搜索
- 对于 Android: ctrl + 空格 = 语言布局切换*

• fn + 向左箭头 = 起始


对于 Windows: alt + shift = 语言布局切换*

请注意: 要选择功能键, 请按住 fn 键, 然后按上方显示的键。

- *语言布局切换:
- 1. 选择适用于操作系统的按键组合。
- 2. 请确保系统提供一种以上的语言布局以供切换。

使用您的产品

状态指示灯



指示灯	说明
闪烁绿灯	电池正在充电。
稳定绿灯	充电情况下,表示电池已充满 (100%)。
	按电池电量检查键时,亮起 2 秒稳定绿灯表示电池电量充足(高于 20%)。
闪烁红光	电量不足(<20%)。为电池充电。
稳定红灯	首次开启键盘时,如果电池电量低,状态指示灯将亮起短暂的稳定红灯。
闪烁蓝灯	快速:键盘处于可被搜索状态,已准备好可以进行配对。
	缓慢:键盘正在尝试重新连接平板电脑。
稳定蓝灯	蓝牙配对或重新连接成功。

连接其他设备

- 1. 确保键盘处于开启状态。
- 2. 确认设备的蓝牙功能处于开启状态。依次选择:"设置" > "蓝牙" > "开启"。
- 3. 按住键盘上的蓝牙连接键 2 秒钟。键盘在 3 分钟内 将变为可被搜索状态。
- 4. 在"设备"菜单中选择"Keys-To-Go AW"。



使用选购的智能手机支架

- 1. 将支架与键盘连接。
- 2. 将智能手机放在支架上。
- 3. 随即可以进行输入。







产品使用完毕后

不使用时, 请关闭键盘以节省电池电量。





请注意:

·如果键盘处于开启状态而在 2 小时内未使用,则会进入休眠模式。按任意键退出休眠模式。

电池废弃处置

1. 沿键盘上边缘切开织物:




2. 使用螺丝刀将"开/关"按钮周围区域的织物撬开:



3. 将内层织物与外层织物分离,然后将其从 边角拉出:



4. 向后拉动黄色隔板,露出电池,将其 拆下:



5. 根据当地法律对电池进行弃置。



访问"产品支持"

我们的网站提供有关于本产品的详细信息和支 持服务。请抽时间访问"产品支持",了解关 于新蓝牙键盘的更多信息。

浏览在线文章,查看安装帮助、使用技巧以及关于更多功能的信息。如果蓝牙键盘有可选软件,请了解其优点以及如何帮助对键盘进行自定义。

通过"社区论坛"与其他用户交流,获得建议,提出问题,分享解决方法。

"产品支持"提供了广泛的内容选择:

- 教程
- · 疑难解答
- ・支持社区
- · 在线文档
- ・保修信息
- · 备用部件(若有供应)

访问:

www.logitech.com/support/ keystogo-tablet

疑难解答

键盘不工作

- · 按任意键即可将键盘从休眠模式中唤醒。
- · 将键盘关闭, 然后再将其重新开启。
- ・ 为内置电池充电。有关详细信息,请参见 "为电池充电"。
- · 在键盘与平板电脑之间重新建立蓝牙 连接:
 - ·确认平板电脑的蓝牙功能处于开启 状态。
 - · 按住键盘上的蓝牙连接键 2 秒钟。
 - · 在平板电脑的"设备"菜单上选择 "Keys-To-Go AW"。蓝牙连接成功后,状态指示灯短暂变为蓝灯。

请注意:如有任何语言方面的兼容性问题,请尝试在平 板电题上安装"Logitech Keyboard plus"应用程序, 或者既系罗技客服人员了解相关详情,网址如下: www.logitech.com/support/keystogo-tablet

您对本产品有何感想?

感谢您购买罗技产品。请拨冗告诉我们您的意见。

www.logitech.com/ithink



www.logitech.com

www.logitech.com/support/keystogo-tablet

© 2015 Logitech. All rights reserved. Logitech, the Logitech logo, 罗技, and other Logitech marks are owned by Logitech and may be registered. Android™ is a trademark of Google Inc. Windows* and the Windows logo are trademarks of the Microsoft group of companies. The *Bluetooth** word mark and logos are registered trademarks owned by Bluetooth* SIG, Inc. and any use of such marks by Logitech is under license. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

版权所有 © 2015 年罗技。罗技、罗技标志、Logitech 和其他罗技商标均归罗技所有,Android™ 是 Google Inc. 的商标。 Windows* 和 Windows 标志是 Microsoft 集团公司的商标 Bluetooth™ 文字商标和标志为 Bluetooth™ SIG, Inc. 所有的注册商标,罗技对此类商标和标志的所有使用均已获得授权。所有其它商标均是其各自所有者的财产。罗技对于本手册中可能出现的任何错误不承担任何责任。本手册中包含的信息如有更改,恕不事先通知。

621-000469.002